

6000counts

Pocket Digital Multimeter User's Manual

Index






1. Overview.....	1
2. Safety precautions.....	1
3. Operation panel instructions	3
4. Characteristics.....	4
5. Automatic boot.....	17
6. Troubleshooting.....	17

1. Overview

The 6000counts is a pocket-sized 3 1/2-bit automatic digital instrument. It has a stable performance, high precision, high reliability clear readings, and overload protection. With AAA 1.5V battery-driven, the instrument uses a large-screen LCD display, boost power supply, even in the 2.3V low battery edge, it can guarantee the backlight high brightness, the table is easy to carry, is a vast number of users extremely like the instrument, the backlight can be bright can be automatically turned off after 15 seconds. This series of instruments can be used to measure the DC voltage and AC voltage DC current and AC current、 resistance、 capacitance diode 、continuity test, zero fire wire judgment, frequency measurement and true RMS measurement and other parameters. Is an ideal tool for the laboratory, factory, radio enthusiasts and families.

2. Safety precautions

This series of instruments is designed to comply with IEC1010 (International Electron-technical Commission promulgated safety standards), before use, please read the safety precautions.

1. When measuring the voltage, please input the limit voltage of DC 1000V or AC 750V rms.
2. The voltage below 36V is safe voltage. When measuring above 36V DC and 25V AC voltage, check whether test pen is reliable contact or right connected or good insulation properly, whether insulation is good and so on, in order to avoid electric shock.
3. When change function and range, test pen should leave the test point.
4. Select the correct function and range, guard against accidental operation. The series of instruments although there is full-range protection, but for safety reasons, you still should pay more attention.
5. When measuring current, do not input batteries more than 10A.
6. Safety Symbol Description, “” Exist dangerous voltage, “” Ground , “” Double insulation, “” Operator must refer to the instruction manual, “” Low voltage symbol.

3. 三、 Operation panel instructions

1. LCD display;

2. MAX/MIN measurement key,

to turn the flashlight on and off;

3. RANGE is a manual range conversion key, which is a REL

relative measurement function when tested in the capacitance file;

4. HOLD is the data retention key. Press and hold for 3 seconds for

the backlight to turn on. Press and hold for 2 seconds for the backlight

to turn on and off (the backlight will automatically turn off after 15 seconds);

5. Function selection key;


6. Gear function selection keys;

7. Voltage, resistance, diode, capacitance, frequency, square wave output,

current input port;

8. COM input; negative input, insert black pen;

9. 10A input port .



4. 四、Characteristics

1. General Characteristics

1-1.Display, liquid crystal display (LCD);

1-2.Maximum display: 5999 (3 5/6) bits automatic polarity display;

1-3.Measurement: double integral A / D conversion;

1-4.Sampling rate: about 3 times per second;

1-5.Overage display: the most significant bit was "0L";

1-6.Low voltage display: “” symbol appears;

1-7.Working environment: (0~40)°C, relative humidity<80%;

1-8.Power supply: AAA 1.5V battery;

1-9.Volume (size): 142×70×32mm(L×W×H);

1-10.Weight: about205g (including 1.5V battery);

1-11.Attachment: a manual, a certificate, a box, a pair of pen, two AAA1.5V batteries.

2. Technical characteristics

2-1. Accuracy (reading data of a%+ least significant digits), guaranteed accuracy environment temperature: $(23 \pm 5) ^\circ\text{C}$, relative humidity <75%, calibration guarantee period from the date of manufacture for one year.

2-2. Performance (Note “▲” Indicates that the instrument has this function.)

Symbol function	
DC voltage DCV	▲
AC voltage ACV	▲
DC current DCA	▲
AC current ACA	▲
Resistor \Diode\ On-off	▲
Frequency F	▲
Capacitance C	▲
NCV	▲
Zero line / Fire wire test	▲
Full unit symbol	▲
Backlight manual/Auto off	▲
True RMS measurement	▲

2-3. Technical specifications

2-3-1. DC voltage (DCV)

Accuracy Range	6000counts	Resolution
6V	± (0.5%+3)	0.001V
60V		0.01V
600V		0.1V
1000V	± (0.8%+10)	1V

Input impedance: 10M Ω ; Overload protection: 6V range is 550V DC or AC peak;


The rest is 1000V DC or 750V AC peak.

The specific operation is as follows: as shown on the right

1. Insert the black test lead into the "COM" socket. The red test pen into the "V / Ω / Hz" jack;
2. Turn the range switch to the corresponding range " $\overline{\text{V}}$ " and display the DC voltage measurement mode.
3. The test pen to reliably touch the test point, the screen shows the measured voltage value, display the DC voltage measured, the red pen is connected to the point of the polarity of the voltage.

Note:

- 1) Do not input voltage exceed DC1000V or AC750V, if do, there will damage the instrument circuit;
- 2) When measuring high voltage circuit, pay special attention to avoid electric shock;
- 3) After completing all measuring operations, disconnect the test leads from the circuit under test.



2-3-1. AC voltage (ACV)

Accuracy Range	6000counts	Resolution
6V	$\pm (0.8\%+3)$	0.001V
60V		0.01V
600V		0.1V
750V	$\pm (1.2\%+10)$	1V

Input impedance: $10M\Omega$; Standard sine wave and triangular wave frequency response is 40Hz-1kHz; Other wave forms are: 40Hz-200Hz.


The specific operation is as follows: as shown on the right

1、 Insert the black test lead into the "COM" socket while the red test lead into the "V / Ω / Hz" jack.

2、 Turn the range switch to " \tilde{V} ", to display the AC voltage auto measurement mode.

Note:

- 1)、 Before test there exists some residual numbers in the range, but does not affect the measurement accuracy;
- 2)、 Do not input voltage exceed 750 Vrms, if do, there will damage the instrument circuit;
- 3)、 When measuring high voltage circuit, pay special attention to avoid electric shock;
- 4)、 After completing all the measuring operations, disconnect the test leads from the circuit under test.



2-3-3.DC Current (DC mA)

Accuracy	6000counts	Resolution
Range		
60mA	± (1.2%+10)	10uA
600mA		100uA

The maximum measured pressure drop: 600mV;

Overload protection: 60mA/600mA:600mA/250V Speed Glass Fuse;

The specific operation is as follows:


The right figure is DC mA schematic diagram,

1.Insert the black test lead into the "COM" socket, insert the red test "SELECT" key to switch between AC and DC current;

2. Turn the range switch to the corresponding DCA position, then insert the instrument into the circuit pending to test. The current value of the measured current and the polarity of the red test point will also be displayed on the screen at the same time.

Note:

- 1) The instrument series connection to the circuit pending to test before the circuit should be the first power off;
- 2) If there is no concept of the measured current range in advance, the range switch should be transferred to the highest range, and then according to the display value to the corresponding file; such as the screen display "0L" that has exceeded the range, needed to turn the range switch to the appropriate gear ;
- 3) The maximum input current is 600mA (depending on the location of the red test pen inserted), excessive current will damage the ma file fuse.
- 4) When the test leads are plugged into the current input terminals, do not connect the test leads to any circuit in parallel or it will damages the fuses and the instrument.
- 5) After the completion of all the measurement operation, you should first turn off the power and then disconnect the test leads and the measured circuit connection, especially to high current measurement.
- 6) It is forbidden to input more than 36V DC, 25V AC voltage between the current jack and the "COM" jack.



2-3-4.DC Current (DC u A)

Accuracy Range	6000counts	Resolution
	600uA	± (1.2%+10)
6000uA	1uA	

The maximum measured pressure drop: 600mV;

Overload protection: 600uA/ 6000uA:600mA/250V Speed Glass Fuse;


The specific operation is as follows: The figure on the right shows the schematic diagram of DC u A.

1、 Insert the black test lead into the "COM" socket, insert the red test lead into the "mA / uA" jack (max. 600mA), "SELECT" key to switch between AC and DC current;

2.Turn the range switch to the corresponding DC/AC u A position, then insert the instrument into the circuit pending to test. The current value of the measured current and the polarity of the red test point will also be displayed on the screen at the same time.

Note:

- 1) The instrument series connection to the circuit pending to test before the circuit should be the first power off;
- 2) If there is no concept of the measured current range in advance, the range switch should be transferred to the highest range, and then according to the display value to the corresponding file; such as the screen display "0L" that has exceeded the range, needed to turn the range switch to the appropriate gear ;
- 3) The maximum input current is 6000uA (depending on the location of the red test pen inserted), excessive current will damage the mA file fuse.
- 4) When the test leads are plugged into the current input terminals, do not connect the test leads to any circuit in parallel or it will damages the fuses and the instrument.
- 5) After the completion of all the measurement operation, you should first turn off the power and then disconnect the test leads and the measured circuit connection, especially to high current measurement.
- 6) It is forbidden to input more than 36V DC, 25V AC voltage between the current jack and the "COM" jack.



2-3-5.AC Current (AC mA)

Accuracy Range	6000counts	Resolution
60mA	± (1.2%+10)	10uA
600mA		100uA

The maximum measured pressure drop: 600mV; Overload protection:
60mA/600mA:600mA/250V Speed Glass Fuse;


The specific operation is as follows: The diagram on the right is the DC mA schematic diagram.

1.Insert the black test lead into the "COM" socket, insert the red test lead into the "mA / uA" jack (max. 600mA), "SELECT" key to switch between AC and DC current;

2.Turn the range switch to the corresponding DC/AC mA gear, trigger "SELECT" to select AC mA and then put the meter into the circuit under test. The measured current value and the current polarity of the red test lead will be displayed at the same time on the screen.

Note:

- 1) The instrument series connection to the circuit pending to test before the circuit should be the first power off;
- 2) If there is no concept of the measured current range in advance, the range switch should be transferred to the highest range, and then according to the display value to the corresponding file; such as the screen display "0L" that has exceeded the range, needed to turn the range switch to the appropriate gear ;
- 3) The maximum input current is 600mA (depending on the location of the red test pen inserted), excessive current will damage the mA file fuse.
- 4) When the test leads are plugged into the current input terminals, do not connect the test leads to any circuit in parallel or it will damages the fuses and the instrument.
- 5) After the completion of all the measurement operation, you should first turn off the power and then disconnect the test leads and the measured circuit connection, especially to high current measurement.
- 6) It is forbidden to input more than 36V DC, 25V AC voltage between the current jack and the "COM" jack.



2-3-6.AC Current (AC u A)

Accuracy	6000counts	Resolution
Range		
600uA	± (1.2%+10)	0.1uA
6000uA		1uA

The maximum measured pressure drop: 600mV;


Overload protection: 600uA/ 6000uA:600mA/250V Speed Glass Fuse;

The specific operation is as follows: The figure on the right shows the schematic diagram of DC u A.

1. Insert the black meter pen into the "COM" jack and the red meter pen into the "V/Ω/Hz" jack; the default value of the current is DC, trigger the "SELECT" button to switch between AC and DC current;
2. Turn the range switch to the corresponding DC/AC u A gear, trigger the "SELECT" key to select AC m A and then put the meter into the circuit to be measured. The measured current value and the current polarity of the red test lead will be displayed at the same time on the screen.

Note:

- 1) The instrument series connection to the circuit pending to test before the circuit should be the first power off;
- 2) If there is no concept of the measured current range in advance, the range switch should be transferred to the highest range, and then according to the display value to the corresponding file; such as the screen display "0L" that has exceeded the range, needed to turn the range switch to the appropriate gear ;
- 3) The maximum input current is 600mA (depending on the location of the red test pen inserted), excessive current will damage the mA file fuse.
- 4) When the test leads are plugged into the current input terminals, do not connect the test leads to any circuit in parallel or it will damages the fuses and the instrument.
- 5) After the completion of all the measurement operation, you should first turn off the power and then disconnect the test leads and the measured circuit connection, especially to high current measurement.
- 6) It is forbidden to input more than 36V DC, 25V AC voltage between the current jack and the "COM" jack.



2-3-7. AC/DC 10A Current (DC/ACA)

Accuracy	6000counts	Resolution
6A	± (2.0%+30)	0.01A
10A		0.01A

The maximum measured pressure drop: 600mV;


Overload protection: 6A/10A: 10A:10A/250V Speed Glass Fuse;

The specific operation is as follows: The figure on the right shows AC and DC 6A/10A

1. Insert the black meter pen into the "COM" jack and the red meter pen into the "V/Ω/Hz" jack; the default value is DC, triggering the "RANG" button to switch between automatic/manual 6A/10A currents;
2. Turn the range switch to the corresponding DC/ACA position. The default value is AUTO DC6A/10A. Then connect the meter to the circuit under test. The measured current value and the current polarity of the red test point will be displayed on the screen at the same time. Trigger "SELECT" key to select AC current AC6A/10A;

Note:

- 1) The instrument series connection to the circuit pending to test before the circuit should be the first power off;
- 2) The maximum input current is 10A (depending on the insertion position of the red meter pens), not more than 10 seconds, excessive current will cause the circuit to heat, or even damage the instrument;
- 3) When the test leads are plugged into the current input terminals, do not connect the test leads to any circuit in parallel or it will damages the fuses and the instrument.
- 5) After the completion of all the measurement operation, you should first turn off the power and then disconnect the test leads and the measured circuit connection, especially to high current measurement.
- 6) It is forbidden to input more than 36V DC, 25V AC voltage between the current jack and the "COM" jack.



2-3-8. Resistance (Ω)

Accuracy Range	6000counts	Resolution
600 Ω	$\pm (0.8\%+5)$	0.1 Ω
6k Ω		1 Ω
60k Ω		10 Ω
600k Ω		100 Ω
6M Ω		1k Ω
40M Ω	$\pm (2.5\%+3)$	10k Ω

Open circuit voltage: less than 3V; overload protection: 550V DC or AC peak;


The specific operation is as shown in the right figure;

1. Insert the black test pen into the "COM" socket while the red test pen leads into the "V / Ω / Hz" jack.


2. Rotate the dial to the " Ω " position, trigger the "SELECT" key and select the resistance grade for automatic measurement.

Note:

- 1) When measuring low resistance, the table will bring the internal resistance, in order to obtain accurate readings, you can firstly record the short-circuit value of the table pen, by testing value minus the short-circuit value.
- 2) When measuring the on-line resistance, please make sure that all the circuits under test must be turned off and all capacitors fully discharged in order to ensure the measured value accurately.
- 3) Do not enter the voltage in the resistance range, which is absolutely prohibited, although the instrument in the gear on the voltage protection.



2-3-9. Diodes and on-off test


Range	Display value	Test Conditions
	Diode forward voltage drop	Positive DC current of about 1mA, open circuit voltage of about 3V,
	The buzzer buzzes for a long time, and the test resistance is less than $(50 \pm 20) \Omega$	Open circuit voltage is about 3V Press "SELECT" to switch between two functions

Overload protection: 550V DC or AC peak;

Warning: for safety, disable the input voltage value in this range!

1. Insert the black test lead into the "COM" socket while the red test lead into the


"V / Ω / Hz" jack (note the polarity of the red test pen is "+");

2. Set the range switch to " grade, trigger the "SELECT" key, select the diode measurement, and connect the test leads to the diode was not tested. The reading is an approximation of forward voltage drop of the diode. For silicon PN junction, 500mV ~800mV confirmed as normal; if the measured diode open circuit or reverse polarity, then display "0L";

3. Trigger the "SELECT" key to select the buzzer measurement and connect the test leads to two points of the circuit pending test. If the built-in buzzer sounds and the on-off alarm indicator is on, the resistance between the two points is below $(50 \pm 20) \Omega$.


Note :

Do not input " voltage symbol, so as not to damage the instrument.



2-3-10.Capacitance(C)

Accuracy Range	6000counts	Resolution
60nF	$\pm (3.5\%+20)$	10pF
600nF		100pF
6uF		1nF
60uF		10nF
600uF		100nF
6mF	$\pm (5\%+3)$	11uF
30mF		10uF



Overload protection: 550V DC or AC peak

1. Insert the black test pen leads into the "COM" socket while the red test pen leads into the "V / Ω / Hz" jack;
2. Rotate the dial to the " Ω " position, trigger the "SELECT" key, and select the capacitance profile for automatic measurement.
3. Then connect the test leads across the measured capacitance.

Note:

- 1) When measuring the capacitance with 10nF range, there may be residual reading on the screen display value. Which is the distributed capacitance of the test pen. For an accurate reading, which can be subtracted after measurement.
- 2)When large capacitance stalls is measuring serious leakage or breakdown capacitor, it will show some unstable values; it is normal that be measuring large capacitors, the reading takes a few seconds to stabilize.
- 3) Please test the capacitor capacity before the capacitor should be fully discharged to prevent damage to the fuse and instrumentation.
- 4) Unit: 1F = 1000mF 1mF = 1000uF 1uF = 1000nF 1nF = 1000p

2-3-11. Frequency measurement:

Accuracy Range	6000counts	Resolution
10Hz	$\pm (0.1\%+3)$	0.01Hz
100Hz		0.1Hz
1kHz		1Hz
10kHz		10Hz
100kHz		100Hz
1MHz		1kHz
10MHz		10kHz


Input sensitivity: 1V rms; Overload protection: 550V DC or AC peak (less than 10 seconds)

Frequency measurement:

1. Insert the test leads or shielded cables into the "COM" and "V/ Ω /Hz" jacks;
2. Turn the range switch to "Hz" and connect the test leads or cables to the signal source or load under test.

Note:

- 1) When the input exceeds 10Vrms, it can be read, but it may be out of tolerance;
- 2) In the noise environment, it is better to use shielded cables when measuring small signals.
- 3) When measuring high voltage circuits, special attention must be paid to avoid electric shocks;
- 4) Do not input more than 250V DC or AC peak voltage to avoid damage to the instrument.



2-3-12. Zero Line/FireWire Measurement (TEST)

The operation is as follows: (above right)

- 1、 Rotate the dial to the "TEST" position(LCD displays "0" in the absence of measurement);
- 2、 The red test pen leads into the "V / Ω / Hz" jack. (single meter operation can be)
- 3、 Insert the tip of the red table into the neutral or fire wire. If it is a fire wire, the buzzer will emit a continuous sound, and the backlight will be turned on.

The LCD screen will display "OL" . If it is a zero line, the meter will be turned on;



Note:

- 1)、 This function is suitable for frequency signals of 50Hz-1kHz.

2-3-13. NCV measurement:

The operation is as follows: (lower right figure)

- 1、 Rotate the dial to the "NCV" position(LCD displays "EF" in the absence of measurement);
 - 2、 The instrument has the NCV test point at its front end.
- As long as the point is close to the AC voltage, the buzzer will emit different continuous sounds according to the signal's different intensity. At the same time, the LCD will display different segments according to the strength of the signal.



5. Automatic Startup & Shutdown

When the instrument stops using for about 15 minutes, the meter will automatically power off to enter the sleep state; to restart the power, dial to the OFF position, turn the knob to other gears. Hold down the "SELECT" button, and turn on the power switch at the same time, the screen "APO" symbol disappears, will cancel the automatic shut down function.

6. Troubleshooting

If your instrument does not work, the following method can help you solve the general problem, if the fault still can not be excluded, please contact the service center or dealer.

Failure phenomenon	Check the location and methods
Not shown	Battery not connected
	Replace the battery
Low battery symbol	Replace the battery
Current is not input	Replace fuse
Resistance display error	The test pen is not in contact

Once this manual is being changed without notice.

These contents of this manual included are considered to be correct, if the user found errors, omissions, etc., please contact the manufacturer directly.

The company does not undertake due to user error operation and the harm caused by the accident

The functions described in this manual are not intended to reasons of the product for special purposes.

6000-108A-00ZJ