




1.Part Name



| | |
|---|--------------------------------------|
| (1), The hole for inserting cord | (2), Knob for sending speed |
| (3), Knob for sending tin | (4), Model change switch |
| (5), Switch | (6), The cover of sending tin |
| (7), Diameter circle for adjusting tin line | (8), Tension adjustment equipment |
| (9), Sending tin gear | (10), Tension adjustment knob |
| (11), Tension gear | (13), Adjustment return tin quantity |
| (12), Sending tin gear | (14), Providing tube |
| (15), Sending tin tube | (16), The stick for release |
| (17), Tension adjustment equipment | (18), Screw for outing tube |
| (19), Tension adjustment knob | (20), Tin line axes |



2.Specifications

373 Complete-Automatic Outing Tin System

| | |
|-------------------|------------|
| Power Consumption | 5W |
| Motor Speed | DC24V 3.2W |

Application Tin Cord (Max Volume 1Kg Axes)

| | |
|-----------------------|--------------------------|
| Tin Cord Diameter(mm) | 0.6、0.65、0.8、1.0、1.2、1.6 |
|-----------------------|--------------------------|

Domination Station

| | |
|-----------------------------------|--|
| Sending Tin Time:0s-7s | Sending Tin Speed:4.5-26mm |
| Dimensions:107(W)x110(H)x215(D)mm | Sending Tin quantity:0-182mm/s |
| Weight:About 1,500g | Return Tin quantity:0-5mm(Stability Speed) |

Notice:
 ○ Setting anti-static disposal.
 ○ Without notice ,when the specification & showing change in anytime.

3.Operation in safety condition

⚠ WARNING

In this instruction manual , "warning " & "caution " are defined as follows :

Warning :Misuse may potentially cause death ,or serious injury to the user .

Notice :Misuse may potentially cause death , serious injury to the user,or the damage to the equipment .

Remark :The key point for operation

For example : Instructions for special process ,dealing with .

●For you own safty,be sure to comply with the following precatons.

CAUTION


- Setting the soldering tip after it is cool
- Turn on the power comes from the voltage by switch .
- Do not bend the transmission tube ,prevent from damage .
- Turn on the transmission tube in order to clean welding tin draft .
- When the tube is bend or upright ,do not use or damage to the tube .
- Do not adjust screws or return quantity ,it is damage to equipment .
- Sending tin gear & tension is pasted together ,cleaning by brush .

4.Assembly

Make sure the parts is suitable for soldering iron & soldering diameter .

A . Adjusting setting of the tin diameter .


- Pull-out the cover of the soldering station & tension knob by forceps in opposition direction.
- Put the ring is adjusting tin line on the tension gear ,adjusting position as formerly.



B . Leading tube assembly setting .

- The tube is between Leading tube assembly and screws .After fixed,it is using wave pad when is needed .


⚠Caution: ■ Setting the soldering tip after it is cool .
 ■ not bend the transmission tube ,prevent from damage .
 ■ When the tube is bend or upright ,do not use or damage to the tube .



C .Outting tin setting

- When you set the tube is in-double-floor ,inside inserts tie-in diameter is covered by a black out tube part . Do not bend the soft tube.

- Put the accessories in the handheld .



D. Setting the tin line

- Getting out the double tin-line , changing a new one .

1. Basing on you are welding element diameter , setting the tin line rolls . Then put line axes into tin line axes . following :



- Put the tin line into the leading tip .
- The 1cm tin line is released by tension gear . When the power is on , model is by hand .
- Turn on the switch by hand , and send tin .

E. Change the diameter of the tin line

- The diameter adjustment equipment can change the diameter when you are working all the time . The leading tube is changed by different diameter . Assembly for making sure following :

- The ring for adjustment tin line diameter
- Leading tip
- Leading tube assembly
- Outing tin assemble

- The left tin line can be returned , you open release setting when power is on .
- Change the diameter ring bases on different tin line by tension adjustment eqiment . Loosing the tension gear axes by forceps .
- If it is necessary , please change leading tube assembly .

5. Operation Method

A. Operation way

- Automatic : You turn on the power switch . When you set the time & speed at a fixed time , it is done by itself as you set .
- By-hand : You turn on the power switch . Sending the tin bases on setting speed .

B. Adjustment sending tin position

- When the tin line into the tube , please get it out , and adjust it .

- Loose the screw cap of the leading tube , adjust the leading tube & tip position . Later fixed the screw .

⚠ Caution :

- Do not fixed screw in the tube tightly , or damage to the tube .
- Prevent scald , adjustment after cool later .

C. Setting the time & speed


- Setting the speed early than time . Speed model **AUTO** & **MANUAL** . Time model **AUTO** efficiency .

D. Setting the return tin quantity

- After sending tin line , set a fixed distance (0-5mm) for return tin by robot . Please the min quantity , if it is beyond the min , and return it . when the tin line gets to tube , The tin solvent is easy to be cohered . In order to prevent this happened , the tin must be returned back by "+"-screwdriver . the right is more , and left is less .

E. Adjustment the tension

- When you adjust the tension , do not the gear loosen , or do not send the tin line when the tin jam happened . Please set the loosen gear tension , use thin tin line (diameter 0.6mm , 0.8mm , 1.6mm) for you reference . following :



| Tin line diameter | ℓ |
|-------------------|-----------|
| φ0.6 | Max |
| φ1.0 | About14mm |
| φ1.6 | About10mm |

6. Avoiding Trouble Manual

If there some wrong with the sending tin , you can check following :

| Trouble Reason | Avoiding |
|--|---|
| Please choose the proper part bases on tinline diameter or not ? | Check tin line diameter part |
| Insert the min receptacle or not ? | Check the receptacle tin is inserted exactly or not? |
| Adjust tension accurately or not ? | Check adjust tension accurately or not ? |
| Fuse is bad or not ? | Check the fuse is bad or not? |
| The soft tube is bend or not ? | Check soft tube is bend or not? |
| The power is on or not ? | Check power is on or not ? |
| The tin line is pasted on sending gear or tension stick or not? | Check the tin line is pasted on sending gear or tension stick or not? |
| Is it right for sending time or speed ? | Check it is right for sending time or speed |
| Is it normal for the temperature ? | Check the tip is normal for the temperature |