

Operation steps

**Check the machine**

Plug the machine to be sure the machine is power on then press “ POWER ”, in this case the power indicator lights and LED display says “ 300 ”.

**Uncover the lip and fill the tank with tap water.**

No water operation will damage the machine, please put the cleaning objects in the water. Fully immerse the part to be cleaned in the water, but do not over the MAX line.

**Time setting**

Press “ TIMER ” to choose the amount of time you wish the items to be cleaned. There are 18 times for option 90s 120s 150s 180s 210s 240s 540s 720s 900s 18m 21m 24m 27M 30M.

**Degas**

Press “ Degas ”, the machine will work for 6 seconds and stop for 3 seconds.

**Finish work**

Please do unplug the machine first after working, and then clean the tank. Be sure no liquid is in the tank if need long-term storage.