

感谢您使用我们的产品，为了您能够安全使用这款新产品，请在使用前仔细阅读使用书。请保管此说明书以备将来使用。请勿随意尝试拆卸或改装本机！

Thank you for using our products. For the safe of use of this new product, Before operating this unit, please read these instructions completely and save this manual for future use. Please do not attempt to disassemble or modified the machine !

产品示意图 SCHEMATIC DIAGRAM



- 2 贴合压力表 Laminating Pressure
- 3 触控系统 Touch Syetem
- 4 除泡压力表 Debubbles Pressure
- 5 透明盖板 Transparent cover

- 6 贴合仓 Laminating tank
- 7 除泡仓 Debubble tank
- 8 散热风扇 Cooling fan
- 9 贴合压力调节 Laminating Pressure Regulator
- 0 电源 Power Supply

规格参数 PARAMETER

型号\MODEL	TBK-408A
电源\SUPPLY	AC220V\110V可定制
功率\POWER	800W
尺寸\SIZE	490*440*320MM
包装\PACKAGING	560*540*430MM
净重\NET WEIGHT	40KG
毛重\GROSS WEIGHT	48KG
除泡\ADDITION BUBBLE	120*200MM
贴合\LAMINATING	230*320MM

产品介绍 PRODUCTINTRODUCTION

这是一台自动气锁贴合除泡一体机,该贴合机无需外接空压机和真空泵,自动抽真空、贴合除泡、自动锁门一次完成,做到完美无泡

This is laminating remove bubble with automatic lock gas ,no need connect air compressor and vacuum pump,automatic evacuate,laminating and remove bubble,automatic lock door can do one time,can do 100% no bubble

操作步骤:
Operating steps

- 1.首先设置真空时间15S、贴合35S、除泡3Min、温度40℃
- 2.点“自动”开始预热
- 3.打开贴合仓
- 4.撕下LCD保护膜放置于定位模具内
- 5.将带有支架的盖板轻轻放到LCD上面
- 6.对好LCD位置后在中间轻轻点一下
- 7.将贴合模具放置在LCD之上
- 8.需要将LCD的边角露出一部分,防止两边压爆角
- 9.盖板朝下整齐摆放在贴合区内
- 10.然后盖上盖子,按“启动”键
- 11.等待设定的除泡时间过后,自动排气
- 12.拿出屏幕,操作完成

- 1.First set vacuum time 15s,laminating 35s,remove bubble 3min,temperature 40C
- 2.press "automatic" start pre-heating
- 3.open laminating door
- 4.tear protect film and take inside the mould
- 5.take glass with frame on LCD
- 6.click LCD centre when in right position
- 7.put laminating mould on LCD
- 8.take lcd corner something out,prevent broken lcd
- 9.take glass inside in laminating zone
- 10.then lid on, press start
- 11.after wait setting remove bubble time,automatic exhaust
- 12.take screen out,finish