Инструкция по эксплуатации лазерного дальномера Sndway SW-DS50/70/100/120



User's Manual

Laser Distance Meter











Safety regulations

Please read the safety regulations and operation guide carefully before operating.

- Please read all of the operational guide and safety regulations. in this manual before operation . Improper operations without complying with this manual guided could cause damage to the device, influence on measurement result or bodily injury to the user.
- The instrument is not allowed to disassemble or repair in any ways. It is forbidden to do any illegal modification or performance change for laser emitter. Please keep it out of reach of children and avoid using by any irrelevant personnel.
- It is strictly prohibited to shoot eyes or other parts of body with the laser; it is not allowed take the laser to shoot any objects' surface with strong reflecting.
- A Due to electromagnetic radiation interference to other equipment and devices, please don't use the meter in the plane or around medical equipment, don't use it in inflammable, explosive environment.
- Discarded batteries or meter device shall not processed just like household garbage, please handle them in line with related law and regulations.
- Any quality issues or any questions on the meter, please contact local distributors or manufacturer in time, we are ready to offer solutions for you.

Professional casts quality and good quality gets reputation

DISPLAY/KEYBOARD

Display

Sound/Addition/_

Subtraction

Area/Volume/

Pythagorean

Reference Point/ -


Measuring

Unit Switch

Turn off/

Save -

Remove



Batteries Installation

Battery Installation and Replacement





- Discharge the battery door on the back of device, and place battery according to correct polarity, then cover the battery door.
- Only 1.5 V AAA alkaline battery is applied to the meter.
- · If not used for a long time, please take out the battery to avoid battery corrosion to meter body.

Start the instrument/Menu Setting

Turn on/off the Instrument

Under off status, press button 📾 , device and laser get starting simultaneously and stand by for measurement.

Under on status, long press button for 3 seconds to turn the device off. The device can also be shut off without any operation for 150 seconds.

Unit setting

Long press button [10], reset current measurement unit, the default unit is: 0.000m. There are 6 units for selection.

Length	Area	Volume
0.000m	0.000m ²	0.000m ³
0.00m	0.00m ²	0.00m ³
0.0in	0.00ft ²	0.00ft ³
0 1/16 in	0.00ft ²	0.00ft ³
0'00"1/16	0.00ft ²	0.00ft ³
0.00ft	0.00ft ²	0.00ft ³

Changing Reference Point

Press key to change the reference point.
The device reference point by default is rear.

Delay Measurement

Long press , a second number shows in the screen. User can press to adjust the time. Press to start count down, the measure start when the time turns to 0.

Back Light On/Off

The back light is set to turn on and off automatically. The back light can be on for 15s while operating, and it will be shut off automatically in 15s when there is no operation to the device.

Sound On/Off

Long press button to turn on or off the buzzer.

Self-Calibration

This function can keep the precision of the device. Instruction: Power off, Long press button , and then press . Release the button , then release button till "CAL" and a figure under it display on the screen. User can adjust the figure with button . according to the accuracy of the meter. Adjusting range: -9 to 9mm, then, long press button to save the calibration result.

Length Measurement & Calculation

Single Distance Measuring:

Turn on the laser beam by short press of the button aunder measuring mode, press the button again for single measurement of length, then the measured results displayed in the major display area.

Continuous Measuring:

Long press button under measuring mode and enter into continuous measuring mode.

Maximum measuring result displays in auxiliary display area, present result displays in major display area. Short press button or to exit continuous measuring mode.

Area Measurement:

Press button , _ shows on the screen.

One of the side of rectangle blinking on the display, please follow the below instructions for area measuring:

Press once for length Press again for width

The device calculates and shows the result in the major display area.

The resent measuring result of length is showed in the auxiliary display area. Press ., clear off the result and measuring again if necessary.

Press again to exit the mode.

Volume Measurement

Press button twice to enter volume measurement mode. A will shows on the top of screen. Please follow the below instruction for volume measuring:

Press for Length

Press 📾 again for Width

Press (thirdly for height

The device calculates and shows the result in the major display area.

Press , clear off the result and measuring again if necessary.

Press again to exit the mode.

Painter Function

When the meter is in area mode, you can use the add / subtract function to total up the area of several surfaces.

Press button three times till showing in the display.


Press to measure the height of the wall first;
Press to measure the bottom edge of the first
wall, get the first area in the major display area;
Press to measure the bottom edge of another
wall, get the sum of these two walls.




Repeat these operations for more walls. Press button to clear the previous measuring result and start new measurement.


When there is no data in the Auxiliary Display area, press button to exit the mode.

Pythagoras









There are four Pythagoras modes in case that user gets hard to reach the target.

 Calculate the length of two legs by measuring the hypotenuse and the angle.

Short press a four times, when the hypotenuse of _____ blinking.

Press (a), measure the length of hypotenuse (a), and calculates the angle (a) between the bevel and the bottom at the same time.

Device calculates the horizontal distance (b) and vertical height (h) .

Calculate the hypotenuse by measuring the length of two legs.

Short press five times, when one leg of blinking,

Press 📾 , measure the length of one leg (a) Press , measure the length of another leg (b) Device calculates the length of hypotenuse (x)

- Press six times till the one side of blinking on the screen.
 - Press (a), measure the length of one side (a)
 - Press (a), measure the length of the median line (b)
 - Press (a), measure the length of another side (c) Device calculates the length of the leg in full line (x)
- Press
 seven times till the hypotenuse of ← blinking on the screen.

Press , measure the length of one hypotenuse (a) Press (, measure the length of another hypotenuse (b)

Press , measure the length of one leg (c) Device calculates the length of the leg in full line (x)

Legs must short than hypotenuse, or there will be "Err" shows on screen. In order to guarantee the accuracy, please make sure all measurements are start from the same point.

Addition / subtraction

The device can be used for length addition and subtraction. Press 🐲 to select the function once get the length measuring result.


Short press . "+" shows in the major display area, entering cumulation mode. Value of last measurement and the result of cumulation will be showed on the screen.

Press again, "-" shows in the major display area, entering regressive mode. Value of last measurement and the result of cumulation will be showed on the screen.

Do round-robin selection between continous addition and continuous subtraction by pressing button ...

Not only length can be calculated in addition and subtraction, but area and volume can do the calculation as well. Take area as sample:

Area cumulative function: Measure the first area as showing in PIC1. Then press button . and measure the second area as showing in PIC2, there is a "+" in the left bottom. At last, press button to get the summation result of these two areas which is showing in PIC3.



Record Function

Long press button 🗐 for 3s to record your measuring result under measuring mode.

It can also record the result under Area, Volume and Pythagoras mode. All the calculating records can be saved by the device.

Read / Delete the Record:

Short press button [1], read the records by press button and . Short press to delete recent record and long press to clear up all the records. Press or to exit record mode.

Angle measurement

The angle information is displayed at the top of the screen, and the angle measurement range is -90.0° to 90.0°.

Tips

You may get some warning information as below:

Info message	Cause	Solution Use the device within the range		
Err	Out of distance measurement range			
Err1	Signal is too weak	Chose the surface with stronger reflectance. Use the reflecting plate.		
Em2	Signal is too strong	Chose the surface with weaker reflectance. Use the reflecting plate.		
Em3	Low battery voltage	Change the power supply.		
Err4	The working temperature is out of working range	Use the device in the specified temperature.		
Em5	Pythagoras measuring error.	Re-measure and ensure that Hypotenuse is bigger than Cathetus.		
Em6	Angle sensor error	Depot Repair		

Technology specifications:

Item	Specifications		
Working Range	0.05m - 50m/70m/100m/120m		
Distance measurement precision	±2mm ★		
Measurement unit options	m/in/ft		
Continuous measure- ment function	yes		
Outdoor target reflection board	no		
Area measurement function	yes		
Volume measurement function	yes		
Pythagorean proposi- tion measurement function	Full mode		
Add and subtract meas- urement function	yes		
Delay Measurement	yes		
Min/Max value	yes		
Max storage	30 units		
Automatic backlight	yes		
Buttons/Keys sound	yes		
Laser level			
Laser type	635nm,<1mW		
Automatically cut off laser	20s		
Automatic shutdown	150s		
Storage temperature	1,000		
Working temperature	0°C-40°C		
Storage humidity	20%-80%RH		
Battery	1.5V 2*AAA		
Battery life	8000 times for single measurement		
Angle Range	±90°		
Dimension	112*50*25mm		

Note: Use a target plate to increase the measurement range during daylight or if the target has poor reflection properties.

★ Typical Tolerance: ±2mm, when reflectivity 100% (white surface), environment light <2000 LUX. 25°C Tolerance is usually affected by the distance, reflectivity, and environment light etc. It probably gets tolerance around ± (2mm+0.2mm/m).

Instrument Maintenance:

- The meter should not be stored in high temperature and strong humidity environment for long time; if it is not used very often, please take out the battery and place the meter in the allocated potable bag and store in cool and dry place.
- Please keep the device surface cleaning. Wet soft cloth is applied to clean dust, but erosion liquid is never allowed to use for the meter maintenance.
 Laser output window and its focus lens can be maintained according to maintenance procedures for optical device.

Delivery Package

Please check if the accessories are completed according to the below list.

NO.	Item	Unit	QTY	Note
1 Laser distance meter		рс	1	
2 User's manual		ро	1	
3	3 Portable bag		1	
4 Handstrap		ро	1	
5 Gift box		ро	1	

Note: Battery 1.5V AAA*2pcs (not included)